

## Installation instructions

A set consists of 85 strips 4 cm wide and 8 strips 5 cm wide.

Strip length: 1.60 m.

The 5 cm strips are intended for the center service line when used with the models numbered 40290 + 40250.

Measuring the tennis court, marking the corners.

Laying the 1.60 m U-profile strips

Loosen the court slightly in the places where the sides of the U-shaped strips are to be pressed into the tennis court.

Now push the T-connectors into the bottom of the marking strips and connect them each with a further marking strip.

Then fit the strips into the designated position. Take care, as mentioned above, that the court is soft and well-loosened.

Lay the strips with an expansion joint measuring approx 1 cm. The joint allows a lengthening of the strips, also in times of hot weather.

Stamp the marking strips with a line stamper or a hand stamper (if available). Otherwise a hammer or a pickaxe (long flat underside) may also be used. Finally fix the lines firmly in place with the help of a light hand roller – not with a heavy motor roller.

Washing in or filling in the lines respectively with water or a brush – the line has to be stamped or rolled long enough until it lies completely flat on the court.

In no way should the strips be pressed in with force, the PVC profile must be able to be fixed into the ground with ease.